## **Transport Containers**

### **TB01**

Container	Packing Instructions	Image		
A <b>TB01</b> container should:	To properly pack a TB01 container:			
☐ Hold 30 gallons	☐ Place the medical waste in ASTM-D bags.			
☐ Be 4.0 Cu Ft in size	☐ Secure using a US DOT approved knot.			
☐ Be hinged with a lockable lid	☐ Place it in a transport container.			
☐ Constructed of polyethylene	☐ Close the lockable lid.			
☐ Have a seamless, leak-proof base	☐ Label "Incinerate Only" if applicable.			
☐ Not exceed a limit of 64 pounds gross weight (weight,	Place in the pickup location.			
including the container and waste)				
Users must supply ASTM-D red bags for the container. Waste in this type of container is destined for Stericycle's autoclave unless it is labeled				
"Incineration Only." Flip-top lids and dollies are available through Stericycle.				

### **TB02**

Container	Packing Instructions	Image	
A TB02 container should:	To properly pack a TB02 container:		
☐ Hold 130 gallons	☐ Place the medical waste in ASTM-D bags.		
☐ Be 17.4 Cu Ft in size	☐ Secure using the US DOT approved knot.		
☐ Constructed of polyethylene	☐ Place in the transport container.	3201	
☐ Have a hinged, lockable lid	☐ Close lockable lid when the container is at	3291	
☐ Have a seamless, leak-proof base	capacity.		
☐ Not exceed a limit of 250 pounds gross weight (weight	☐ Label "Incinerate Only" if applicable.		
including container and waste.)	☐ Place in the pickup location.		
Use a TB02 container for large animal waste destined for Stericycle's incinerator. Users must supply ASTM-D red bags for the container. Waste in this type of container is destined for Stericycle's autoclave unless it is labeled "Incineration Only."			

Transport Containers Page 1 Last Updated: 07/17/2019

# **Transport Containers**

## **US43**

Container	Packing Instructions	Image
A <b>US43</b> container should:	To properly pack a US43 container:	
☐ Hold 31 gallons	☐ Tape all the bottom seams of the US43 container securely using	Experience Production for the Production for the Section Section 5. Section 5
☐ Be 18" x 18" x 22" in size	packing tape.	Supplied to the state of the st
☐ Be 4.3 Cu Ft in size	☐ Place the medical waste in ASTM-D bags.	stericycle"
☐ Be constructed of sturdy	☐ Tie the bag or liner in a US DOT approved knot.	8
fiberboard	☐ Place the bag or liner in the approved transport container.	
☐ Have a 64-pound limit.	☐ Tape the lid when the box is at capacity,	
	☐ Label "Incinerate Only" if applicable.	
	☐ Place the container in the pickup location.	
Users must supply ASTM-D red bags for the container. Waste in this type of container is destined for Stericycle's autoclave unless it is labeled		
"Incineration Only."		

## BX05

Container	Packing Instructions	Image
A <b>BX05</b> container should:	To properly pack a BX05 container:	
☐ Hold 15 gallons	☐ Securely tape the bottom seams of BX05 container.	al s
☐ Be 12" x 12" x 22" in size	☐ Place the medical waste in ASTM-D bags.	MCMEATT ONLY
☐ Be 2.0 Cu Ft in size	☐ Tie the bag or liner in a US DOT approved knot or tape down.	in the state of th
☐ Be constructed of sturdy	☐ Place the medical waste in an approved transport container.	Madeiral Wash Systems
fiberboard	☐ Tape the lid when the transport container is at capacity.	
	☐ Label "Incinerate Only" if applicable.	
	☐ Place the container in a pickup location.	
Users must supply ASTM-D red bags for the container. Waste in this type of container is destined for Stericycle's autoclave unless it is labeled		
"Incineration Only."		

Transport Containers Page 2 Last Updated: 07/17/2019